

CONTURA X & XI Rocker Switches

6
9 ACTUATOR

0 - NO ACTUATOR (FURNISHED SEPARATELY)

CONTURA X	BLACK 1	GRAY 2	WHITE 3	RED 4	
CONTURA XI	6	7	8	9	

10 LENS - ABOVE LAMP #1 TERMINALS 1,4
11 LENS - ABOVE LAMP #2 TERMINALS 3,6

0 - NO ACTUATOR **Z** - NO LENS

CLEAR	WHITE	AMBER	GREEN	RED	BLUE	LENS STYLE
3	8	D	J	P	V	BAR LENS I
4	9	E	K	R	W	ONE PIECE ■ SQUARE LENS
5	A	F	L	S	Y	TWO PIECE ■ SQUARE LENS w/clear top protective lens*
2	7	C	H	N	U	TWO PIECE ■ SQUARE LENS w/smoke top protective lens*
1	6	B	G	M	T	TWO PIECE ■ SQUARE LENS w/white top protective lens*

* ALL bottom lenses will be molded of OPAQUE material.
Consult factory for other lens colors.

13 LEGEND ORIENTATION⁴

Field 13 must be 0 if legend code in selection 12 is 11 - 18.

0 - NO LEGEND

1 Position 1
2 Position 2
3 Position 3
4 Position 4

14 ACTUATOR LENS LEGENDS⁴

Field 14 must be 00 if legend code in selection 12 is 11 - 18.

00 - NO LEGEND THIS LOCATION/NO ACTUATOR

FOR LEGEND OPTIONS & CODES, SEE PAGES 19 TO 25.

* Additional orientations and locations for legends available, consult factory.

12 ACTUATOR LENS OR BODY LEGENDS⁴

00 - NO LEGEND THIS LOCATION/NO ACTUATOR

11	ON OFF	15	O F	O N
12	OFF ON	16	O N	O F
13	I O	17	O	I
14	O I	18	I	O

FOR ADDITIONAL LEGEND OPTIONS & CODES, SEE PAGES 19 TO 25.

- NOTES:
- Shading indicates standard configurations. Consult factory to verify horsepower rating for your particular circuit choice.
 - 1 Custom colors are available. Consult factory.
 - 2 Not available on Soft surface actuators. White imprinting is standard on black actuators. Black imprinting is standard on white, red and gray actuators. Custom colors are available. Consult factory.
 - 3 18V bulbs recommended for 13.8 V applications for more pleasing illumination.
 - 4 With two square lenses, use selection 12 for lens above lamp 1, and use selection 14 for lens above lamp 2.

V-Series Components:

To order **switch without actuator** specify: **V** with code selections **2** through **8**.
(ex.) V1DABC01-00000-000

To order **actuator separately**, specify **VV** with code **1-4** or **6-9** for selection 9, and codes from above scheme for selections 10 through 14. (ex.) VV6RZMA-100. To order actuator with openings for lenses and lenses separately