







Surface mount 2 pole



Surface mount 3 pole



Surface mount 3 pole

Features

- AC circuit breaker
- · Hydraulic-magnetic technology
- 100 % rating capability; independent of ambient temperature
- One, two, three, four pole, 1+N and 3+N
- AS/NZS 3111 approved
- Ratings 1 A to 100 A (Verify certification)
- · Available in various current ratings and time delays
- · Precision tripping characteristics
- · Can be switched on immediately after tripping
- · Optional auxiliary switch
- Optional shunt trip (No approvals)

Applications

- AC Branch protection
- Telecom / datacom equipment
- Lighting control
- UPS equipment
- · Mobile power generation equipment
- Railway equipment
- Industrial equipment
- · Mining equipment

Auxiliary Switch: Features

Single pole double throw
 15 A @ 250 Vac

Optional Accessories

- Handle lock
- Safety blank SFM1

Approvals







Technical Data

Product Type			Circuit Breaker				
Approvals			AS/NZS 3111				
Number of Poles	1	2 (1+N)	2	3	4 (3+N)		
Operating Voltages	240 V ac 415 V ac						
Minimum Current Rating	4 A						
Maximum Current Rating	100 A						
Interrupting Capacity	pting Capacity 6 kA						

Product Type	Switch Disconnector								
Approvals	IEC / EN 60947-3								
Number of Poles	1	2	4						
Operating Voltages	240 V ac 415 V ac								
Current Rating	63 A & 100 A								
Withstand Current	6 kA / 50 ms								

Product Type	SFM(26)				
Ambient Operating Temperature	-40 °C to +85 °C				
Mounting Options	Clip tray, Front & Surface mounting				
Time Delay Curves	1, 2, 3				
Endurance	500 mechanical operations (AS/NSZ3111 Clause 7.7)				
Dielectric Strength	2 kV (AS/NZS3111 Clause 7.5.2)				
Weight	200 g per pole, 260 g with auxiliary (unpacked)				
Altitude	Certification tests done at altitude ≈ 2000 metres. Will operate at higher altitudes.				
Shock	50 g with pulse duration of 11 milliseconds				
Vibration	5 g from 35 Hz to 200 Hz				
Flammability	I3 - Ignition does not persist at 850 °C after glow wire is withdrawn with an oxygen index of ≥ 28				
Toxicity	F1 - Smoke index of ≤ 20 which determines the fume class				
Pollution Degree	PD2 - Normally only non-conductive pollution occurs. Temporary conductivity caused by condensation is to be expected.				

Circ	cuit Breaker	Wire Size mm² (IEC)	Torque (IEC)	Comments
Main terminals	Box Type	1 - 35 mm²	4 Nm	Pozidriv #2
	Lug & Rear Studs Type	1 - 50 mm²	4 Nm	Combi head

Verify approvals for specific ratings in accordance with the relevant test certificates.



Long Code

Example Code: SFM4-2G3/G1/G10-60A-2-96-250Vac - AC-3

Group		2								10	11	12	13	14	15	16	17	18	19
Requirement	SFM	Four Pole	Two Pole First Set	Box Type Main Termi- nal	Overload Series Trip	One Pole Sec- ond Set	Box Type Main Termi- nal	Overload Series Trip WITH Aux swich	One Pole Third Set	Box Type Main Termi- nal	Shunt Trip (ST1), flexible leads	N/A	N/A	N/A	Current Rating	Time Delay	Shunt Trip Voltage Vac	AC/DC	AS/NZS 3111
Long Code	SFM	4	2	G	3	1	G	1	1	G	10	-	-	-	60 A	2	96-250	AC	3

Ordering Information

	Group 1:	Code	Description	Comments
	Frame Type	SFM	SFM	
	Group 2:	Code	Description	Comments
	Total Number of Poles	1	Single pole	
		2	Double pole	2 pole or 1+N
		3	Triple pole	
		4	Four pole	3+N
	Group 3:	Code	Description	Comments
	Number of Poles	-	Not applicable	All poles are the same
		2	Two poles	
		3	Three poles	
		4	Four poles	
	Group 4:	Code	Description	Comments
	Termination	Α	Rear studs "AC"	
		D	Screw terminal "AC"	
(s)		G	Box terminal "AC"	
First Set (s)	Group 5:	Code	Description	Comments
st	Pole Construction	0	Switch Disconnector with auxiliary switch fitted	No approvals
iΞ		1	Series trip overload with auxiliary switch fitted	
		3	Overload series trip	
		6	Shunt trip four terminals. (INTERNAL SHUNT)	No approvals
		10	Shunt trip (ST1), flexible leads. (EXTERNAL SHUNT)	No approvals
		11	Shunt trip (ST1). with auxiliary switched fitted. (EXTERNAL SHUNT)	No approvals
		13	Switch Disconnector with auxiliary switch fitted	No approvals
		14	Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT)	No approvals
		15	Auxiliary switch with flexible leads (internal fitted). Occupies additional pole	
	Group 6:	Code	Description	Comments
	Number of Poles	-	Not Applicable	
		/	One pole	
		/2	Two poles	
		/3	Three poles	
		/4	Four poles	
	Group 7:	Code	Description	Comments
	Terminal Type	A	Rear studs "AC"	
(s)		D	Screw terminal "AC"	
Second Set (s)		G	Box terminal "AC"	
5	Group 8:	Code	Description	Comments
မ္မ	Pole Construction	0	Switch Disconnector with auxiliary switch fitted	
Ó		1	Series trip overload with auxiliary switch fitted	
		3	Overload series trip	
		6	Shunt trip four terminals. (INTERNAL SHUNT)	
		10	Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT)	
		11	Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT)	
		13	Switch Disconnector with auxiliary switch fitted	
		14	Shunt trip in series with a cutt-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT)	
		15	Auxiliary switch with flexible leads (internal fitted), Occupies additional pole	



Ordering Information

Number of Poles		Group 9:	Code	Description	Comments
Page		Number of Poles	-	Not Applicable	
A			/2	11	
Group 16:			/3	·	
Terminal Type				·	
Terminal Type		Group 10:	Code	Description	Comments
Group 11:					
Section Sect			D	Screw terminal "AC"	
Section Sect	(s)		G	Box terminal "AC"	
Section Sect	Set	Group 11:	Code	Description	Comments
Section Sect	2	Pole Construction	0	Switch Disconnector with auxiliary switch fitted	
Computation Comments	두		1	Series trip overload with auxiliary switch fitted	
10			3	Overload series trip	
Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT)			6	Shunt trip four terminals. (INTERNAL SHUNT)	
Shunt trip in series with a cut-off main contacts (ST1CO), With flexible leads, Occupies additional pole, (SERIES SHUNT)			10	Shunt trip (ST1), flexible leads. (EXTERNAL SHUNT)	
Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) Soroup 12:			11	Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT)	
Page			13	Switch Disconnector with auxiliary switch fitted	
Group 12: Number of Poles Pole Number of Poles Group 13: Terminal Type Group 14: Pole Construction Group 14: Pole Construction Group 15: Group 15: Group 16: Group 17: Group 17: Group 18: Pole Construction Group 18: Pole Construction Group 18: A Rear studs "AC" D Screw terminal "AC" Group 18: Pole Construction Group 18: A Rear studs "AC" D Screw terminal "AC" Group 18: Pole Construction Group 18: A Rear studs "AC" D Screw terminal "AC" Group 18: A Rear studs "AC" D Screw terminal "AC" G Box terminal "AC" D Switch disconnector with auxiliary switch fitted 1 Series trip overload with auxiliary switch fitted 3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trip (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. Group 15: Code Comments Comments Comments Comments Comments Comments Comments			14		
Number of Poles			15	Auxiliary switch with flexible leads (INTERNAL FITTED). Occupies additional pole	
Four pole 1/3 Three poles 1/4 Four poles			Code	Description	Comments
Group 13: Code Description Comments		Number of Poles	-	Not Applicable	
Group 13: Code			/2	Two pole	
Group 13: Terminal Type Group 14: Pole Construction Group 14: Sories trip overload with auxiliary switch fitted 1 Series trip overload with auxiliary switch fitted 3 Overload series trip 6 Shunt trip (ST1), flexible leads. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted 14 Shunt trip is eries with a cut-off main contacts (ST1CO), With flexible leads. Occupies additional pole Group 15: Code Description Comments			/3	Three poles	
Terminal Type A Rear studs "AC" D Screw terminal "AC" Group 14: Pole Construction O Switch disconnector with auxiliary switch fitted 1 Series trip overload with auxiliary switch fitted 3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip is reires with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Comments			/4	Four poles	
D Screw terminal "AC"			Code	Description	Comments
Group 14: Pole Construction Group 14: Pole Construction Group 14: Description Ouverload series trip Group 14: Series trip overload with auxiliary switch fitted Outerload series trip Group 15: Group 15: Group 15: Group 16: Group 16: Group 16: Group 17: Group 17: Group 17: Group 18: Code Description Comments		Terminal Type	Α	Rear studs "AC"	
3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments	·		D	Screw terminal "AC"	
3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments	et (s		G	Box terminal "AC"	
3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments	Š		Code	Description	Comments
3 Overload series trip 6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments	불	Pole Construction	0	Switch disconnector with auxiliary switch fitted	
6 Shunt trip four terminals. (INTERNAL SHUNT) 10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip is reires with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments	유			Series trip overload with auxiliary switch fitted	
10 Shunt trips (ST1), flexible leads. (EXTERNAL SHUNT) 11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip is series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments			3	Overload series trip	
11 Shunt trip (ST1), with auxiliary switch fitted. (EXTERNAL SHUNT) 13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments			_	, , , , , ,	
13 Switch Disconnector with auxiliary switch fitted 14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments			_		
14 Shunt trip in series with a cut-off main contacts (ST1CO). With flexible leads. Occupies additional pole. (SERIES SHUNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments			11		
14 Occupies additional pole. (SERIES SHÚNT) 15 Auxiliary switch with flexible leads (internal fitted). Occupies additional pole Group 15: Code Description Comments			13	·	
Group 15: Code Description Comments			14		
				Auxiliary switch with flexible leads (internal fitted). Occupies additional pole	
Current Rating 1 2 4 6 10 15 16 20 25 30 32 40 50 63 70 80 100 A Ratings certification dependant			Code	Description	Comments
., _, 1, 0, 10, 10, 10, 20, 20, 10, 00, 10, 10, 10, 10, 10, 10, 10, 1		Current Rating		1, 2, 4, 6, 10, 15,16, 20, 25, 30, 32, 40, 50, 63, 70, 80, 100 A	Ratings certification dependant



Ordering Information


Group 16:	Code	Description	Comments
Time Delay	1	Long time delay	Orange handle
	2	Medium time delay	White handle
	3	Short time delay	White handle
Group 17:	Code	Description	Comments
Shunt Trip Voltage	-	Not Applicable	
	24 - 96	24 - 96 Vac or 12 - 48 Vdc	
	96 - 250	96 - 250 Vac or 48 - 125 Vdc	
	380 -440	380 - 440 Vac	
Group 18:	Code	Description	Comments
AC/DC	AC	Single phase 240 Vac, Three phase 415 Vac	
Group 19:	Code	Description	Comments
Approvals	3	AS/NZS 3111	
	Z	No approvals	

Note:

- 1. Ordering Information
 - Apply first set group's 3, 4 & 5 followed by group 15, 16, 17, 18 & 19 for when all the poles are of the same construction.
 - Make use of codes for groups 6 to 14 of the second set to the fourth set followed by groups 15, 16, 17, 18 & 19 for when all the poles are
 of a different construction.
- 2. Auxiliary and Shunt Information
 - Auxiliary switch is fitted on the left hand side of the first pole of the unit.
 - Shunt trip is fitted on the left hand side of the unit.
 - If shunt trip with auxiliary switch (G11) is selected, then both auxiliary switch and shunt trip is fitted on the left hand side of the unit.




Time Delay Curves






Time Delay Curves






Time Delay Curves






Outline Dimensions: Front & Surface Mount




TOLERANCE ±0.4 UNLESS OTHERWISE SPECIFIED (DIMENSION IN BRACKETS ARE IN INCHES




Outline Dimensions: Auxiliary Switch





NOTES:

- 1 GENERAL TOLERANCE 0.4 mm
- 2 PRODUCT CAN BE OFFERED IN STUD TERMINALS (SHOWN), BOX TERMINALS AND LUG TERMINALS



© CBI (Pty) Ltd. All Rights Reserved.

Please review our Customer Terms and Conditions on www.cbi-lowvoltage.co.za

All rights reserved. Unless otherwise indicated, all materials on these pages are copyrighted by CBI (Pty) Ltd. No part of these pages, either text or image may be used for any purpose other than personal use. Therefore, reproduction, modification, storage in a retrieval system or retransmission, in any form or by any means, electronic, mechanical or otherwise, for reasons other than personal use, is strictly prohibited without prior written permission. CBI (Pty) Ltd reserves the right to alter any details of this document without notice and while every effort is made to ensure the accuracy of the content, no warranty is given as to the accuracy of this document and no responsibility will be accepted for error or misinterpretation and any resulting loss.

AUSTRALIA

CBI-electric: Australia 27 Wedgewood Rd, Hallam Victoria 3803 Australia Tel: +61 3 8752 9300 Fax: +61 3 9796 5407

Email: sales@cbi-electric.com.au Website: www.cbi-electric.com.au

SOUTH AFRICA

CBI-electric: low voltage Tripswitch Drive Elandsfontein Gauteng South Africa Tel: +27 11 928 2000 Fax: + 27 11 392 2354

Email: internationalsales@cbi-electric.com

cbi@cbi-electric.com

Website: www.cbi-lowvoltage.co.za

CBI-electric: North America 35 E. Uwchlan Ave Suite 328 Exton PA 19341 USA Tel: +1 610 524 9949 Fax: +1 610 524 9945 E-mail: info@cbibreakers.com

Website: www.cbibreakers.com

A member of the REUNERT Group